

Mitel 6930 IP Phone - Overview

Quick Video

Quick Reference Guide



Place a Call

- Dial the number from the keypad and press the **Dial (SOFTKEYS)**.
- Press the **SPEAKER/HEADSET** key, and at the dial tone, enter the number.
- Press the **Call Appearance (PROGRAMMABLE KEYS)** and at the dial tone, enter the number.

From Directory

- Press the **DIRECTORY** key to access the Directory.
- Navigate to the respective contacts folder and scroll through the contacts -OR- Enter characters using the keypad and press the **Search (SOFTKEYS)** to use the search feature.
- When the contact is highlighted, press the **SELECT** button or the **Dial (SOFTKEYS)** to place a call using the entry's default phone number -OR- To place a call to a different phone number defined for the entry (for example, a mobile number), press the right navigation key to highlight the phone number you want to call using the up or down navigation keys, and press the **SELECT** button or the **Dial (SOFTKEYS)**.

Answer a Call

- Lift the handset, press the **Answer (SOFTKEYS)**.
- Press **SPEAKER/HEADSET** the key for handsfree operation.

End a Call

- Place the handset back in its cradle.
- Press the **Drop (SOFTKEYS)**.
- Press **GOODBYE** the key.

Redial

- Press the **REDIAL** key twice in quick succession to redial the last dialed number.
- Press the **REDIAL** key once to access a list of recently dialed numbers. Use the up and down **NAVIGATION** keys to scroll through the entries and select a number. Press either the **SELECT** button or the **Dial (SOFTKEYS)** to redial the selected number.

Parking/Unparking a Call

[Click here to see how it's done!](#)

With appropriate permissions (set by your Mitel administrator), you can park a connected call on another extension and you can unpark that call and return it to your extension.

To Park a Call:

1. While the call is active, press the **Park** While on an active call with one of the contacts with whom you want to create a conference, press the Conference softkey. The active call is placed on hold. 2. Enter the conference target's number and press the Consult softkey. 3. Wait for an answer and then press the Conference softkey to complete the 3-way conference call..
2. Dial the extension number. The call is now parked on the designated extension .

To Unpark a Call

1. Press the **Unpark (SOFTKEYS)**.
2. Dial the extension number. The call is now returned to your extension.

Mute/Unmute a Call

- Press the **MUTE** key while on an active call to mute the microphone for your handset, headset, or speaker.
- Press the **MUTE** key again to unmute the audio.

Hold/Resume a Call

- To place an active call on hold, press the **HOLD** key. The LED flashes on the respective Call Appearance programmable key.
- To resume the call, press the **HOLD** key again or press the respective **Call Appearance (PROGRAMMABLE KEYS)**.

Voicemail

When voicemail is enabled, the Message Waiting Indicator (MWI) LED on the phone flashes red and the voicemail icon displays on the status bar indicating that voicemail messages are available. You can access your voicemail service by pressing the **VOICEMAIL** key.

3-Way Conferencing

1. While on an active call with one of the contacts with whom you want to create a conference, press the **Conference (SOFTKEYS)**. The active call is placed on hold.
2. Enter the conference target's number and press the **Consult (SOFTKEYS)**.
3. Wait for an answer and then press the **Conference (SOFTKEYS)** to complete the 3-way conference call.

Transfer a Call

1. While on an active call with the party you wish to transfer, press the **Transfer (SOFTKEYS)**. The active call is placed on hold.
2. Enter the transfer recipient's number and press the **Transfer (SOFTKEYS)**.

Picking Up a Call

With appropriate permissions (set by your Mitel administrator), you can pick up a call that is ringing on another extension.

1. Press the **Pickup (SOFTKEYS)**.
2. Dial the extension number. The call is now an active call on your extension

Softkeys

Pickup	Allows user to pick-up another ringing extension.
Park/Unpark	Allows user to place call on remote hold to another extension or retrieve a call held remotely.
Answer	Answers call on speaker or headset.
To VM	Forwards incoming calls directly to voicemail.
Merge	Joins calls together in conference.
Transfer or Conference	Completes “blind” connection.
Drop	Disconnects selected party on conference call.
More	Displays more options on screen.
Cancel	Returns display screen to previous setting or cancels initiated function.
Silence	Silence ringtone and handle call with configured call-handling rules.

Changing Availability State

You can set six distinct availability states for your extension:

- Available (default)
- Extended Absence
- In a meeting
- Custom
- Out of office
- Do not disturb

To change your active availability state:

1. Press the **State (SOFTKEYS)**. The active state is indicated.
2. Press the left or right **NAVIGATION** key to scroll to the preferred availability state.
3. Press the **Save (SOFTKEYS)**. The availability state for your phone changes to the selected state.

Common Star Codes

Park a Call	HOLD + *11 + extension
Unpark a Call	*12 + extension
Pickup a Remote Extension	*13 + extension
Pickup the Night Bell	*14
Use the Intercom	*15 + extension
Barge In	*16 + extension
Silent Monitor	*17 + extension
Toggle Hunt Group status	*18 + Hunt Group's extension
Whisper Page	*19 + extension
Silent Coach	*22 + extension

Mitel 6930 User Guides



[MiCloud_Connect_6930_IP_Phone_User_Guide-ES.pdf](#)



[MiCloud_Connect_6930_IP_Phone_User_Guide-DE.pdf](#)



[MiCloud_Connect_6930_IP_Phone_User_Guide-FR.pdf](#)



[MiCloud_Connect_6930_IP_Phone_User_Guide-EN.pdf](#)

Mitel 6930 Quick Reference Guides



[MiCloud_Connect_6930_Quick_Reference-ES.pdf](#)



[MiCloud_Connect_6930_Quick_Reference-DE.pdf](#)



[MiCloud_Connect_6930_Quick_Reference-FR.pdf](#)



[MiCloud_Connect_6930_Quick_Reference-EN.pdf](#)